AXS CR 82Ø Mounting of the magnet holder.



	CR 9000 07	12/2019		V1	Page 1 of 2	
	These instructions are for the	replacements of the	magnet h	older in the C	R Ramp	
	These instructions are for the replacements of the magnet holder in the CR Ramp Necessary tools equipment : new magnet holder, a screwdriver , a small/light Hammer, a small plastic hammer and a special daunting tool with marks.					
1	the magnet is on the right-side of long finishing cap carefully with left/right and so on)		e			
2	Open the profile after detaching				3000	
3	 The included daunting tools got on 8 cm before the breat magnet holder on 2 cm before the posit holder. 	kthrough of the old	t	nannentennen annentennen	3 • 4 • 5 • 6 • 7 • 8 • 9 • 10 • 1 • 12	
4	The old mounted holder with ma cm mark point when the magner remove it. When the canal is dirty, just a qu knife and potential with spirit so holder will fit easily.	t is free in the profile, t uick clean up with a sn	ry to			
5	Pay attention on the" teeth" of t	he magnet holder to th	e			
	left being pointed and that de r above. The new magnet holder place a carefully inside tapping.		-			

AXS CR 82Ø Mounting of the magnet holder.



	CR 9000 07	12/2019	V1	Page 2 of 2					
6	Tick The holder carefully inside,	with a plastic hammer							
7	Tick slowly Against the magnet hammer and the daunting tools 1e brand Marks The depth is 20 mm measured till the magnet holder	till it is on his place	file						
8	Replace The plastic end cap								